


5/12/22

Experiment - 5  
Title: Routing information protocol

Aim: Configuring RIP routing protocol.

## Topology:



procedure: \* place 3 generic routers and 2 generic PCs

- \* Connect the router and PC using copper crossover.
- \* Connect the routers using serial DCE with clock symbol.
- \* Place notes near the PCs and routers.
- \* Set the IP address of PC0 and PC1 as well as their subnet mask and default gateway.
- \* Go to the CLI of Router 0 and enter the following commands:
  - enable
  - config

- interface fastEthernet 0/0
- ip address 10.0.0.10 255.0.0.0
- no shut.

- \* The connection should turn green.
- \* Repeat for PC1 and router 2.

#### \* open CLI of router 0.

- enable
- config t
- interface serial 2/0
- ip address 20.0.0.10 255.0.0.0
- encapsulation ppp
- clock rate 64000
- no shut.

#### \* open CLI of router 1.

- enable
- config t
- interface serial 2/0
- ip address 20.0.0.20 255.0.0.0
- encapsulation ppp
- no shut.

- \* The connection will turn green.

- \* → exit
- show ip route

#### \* open CLI of router 1.

- enable
- config t
- interface serial 2/0
- ip address 30.0.0.10 255.0.0.0
- encapsulation ppp



→ clock rate 64000

→ no shut

→ exit

\* open CLI of Router 2

→ enable

→ config t

→ interface serial 2/0

→ ip address 30.0.0.10 255.0.0.0

→ encapsulation ppp

→ no shut

\* open CLI of router 0

→ enable

config # router 0

config-router # network 10.0.0.0

config-router # network 20.0.0.0

config-router # exit

→ show ip route

\* Similarly repeat for router 1 and router 2  
with networks 20,30 & 30,40.

Simulation mode: Add a simple PDU by selecting  
the PC and click on auto-  
capture from right panel.

Real time mode: select PC P0 go to its command  
prompt and select the destination  
address. [Ping 10.0.0.10]  
after this select 20.0.0.10, 30.0.0.10, 40.0.0.10  
as destination address.

Finally ping PC 2 by using its IP address as



the destination address. [ping 40.0.0.1].

Result:  $\Rightarrow$  PC > Ping 10.0.0.10.

pinging 10.0.0.10 with 32 bytes of data:

Reply from 10.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 10.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 10.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 10.0.0.10: bytes = 32 time = 0ms TTL = 255

$\Rightarrow$  PC > Ping 20.0.0.10

pinging 20.0.0.10 with 32 bytes of data:

Reply from 20.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 20.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 20.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 20.0.0.10: bytes = 32 time = 0ms TTL = 255

$\Rightarrow$  PC > Ping 30.0.0.10

pinging 30.0.0.10 with 32 bytes of data:

Reply from 30.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 30.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 30.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 30.0.0.10: bytes = 32 time = 0ms TTL = 255

$\Rightarrow$  PC > Ping > 40.0.0.10

pinging 40.0.0.10 with 32 bytes of data:

Reply from 40.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 40.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 40.0.0.10: bytes = 32 time = 0ms TTL = 255

Reply from 40.0.0.10: bytes = 32 time = 0ms TTL = 255



⇒ PC > Ping 40.0.0.1

Pinging 40.0.0.1 with 32 bytes of data:

Request timed out:

Reply from 40.0.0.1: bytes = 32 time = 16ms TTL = 125

Reply from 40.0.0.1: bytes = 32 time = 17ms TTL = 125

Reply from 40.0.0.1: bytes = 32 time = 13ms TTL = 125

Statistics: sent = 4, received = 3, lost = 1 (25% loss)

⇒ PC > Ping 40.0.0.1

Pinging 40.0.0.1 with 32 bytes of data:

Reply from 40.0.0.1: bytes = 32 time = 2ms TTL = 125

Reply from 40.0.0.1: bytes = 32 time = 2ms TTL = 125

Reply from 40.0.0.1: bytes = 32 time = 1ms TTL = 125

Reply from 40.0.0.1: bytes = 32 time = 1ms TTL = 125

Learnings: Routing information protocol is a protocol that routers can use to exchange network topology information. It is used in small to medium sized networks. A router running RIPv1 sends the contents of its routing table to each of its adjacent routers every 30 seconds.